





Step 1:
Open the
CNDV-700HD Carton.



MEDIA NUMBER CARD	
MODEL#: CNDV-700HD/UC	
MEDIA NUMBER	XXXX1234567890ABCDEF
DEVICE NUMBER	
DO NOT LOSE THIS CARD. RE-CREATION OF THE "MEDIA NUMBER" IS NOT POSSIBLE. The information on this card is required in the upgrade process. Also, this card is necessary as the certification for repair (including recovery). When repair is required for the navigation system, the updated data cannot be compensated if you fail to submit this card. For future reference, fill in "DEVICE NUMBER" (Device Number, Device#) of your navigation system.	

Step 2:
Remove the
CNDV-700HD Media Number
Card (located in the disc case)
DO NOT LOSE THIS CARD
The 20 digit media number is
unique to each CNDV-700HD disc
and installation cannot be
completed without this number.



Menu button


Step 4:

On the Pioneer navigation system, press the “Menu” button and the screen shown below will appear.

Step 3:

Take the CNDV-700HD Media Number card and a pen to the vehicle. You will need to write down the Device Number found within the menu system of the Pioneer navigation system.






Settings
touchscreen button

Step 5:

On the Pioneer navigation system, press the “Settings” touchscreen button and the screen shown below will appear.




Hardware
Touchscreen button

Step 6:

On the Pioneer navigation system, press the “Hardware” touchscreen button and the screen shown below will appear.







Service Info Screen
Touchscreen button

Step 7:

On the Pioneer navigation system, press the "Service Info Screen" touchscreen button and the screen shown below will appear.




Device Number


Step 8:

The Device Number is located in the Service Information Screen.

Write the 16 digit Device Number in the appropriate box on the Media Number card.



MEDIA NUMBER CARD	
MODEL#: CNDV-700HD/UC	
MEDIA NUMBER	XXXX1234567890ABCDEF
DEVICE NUMBER	84DEF053634138B6
DO NOT LOSE THIS CARD. RE-CREATION OF THE "MEDIA NUMBER" IS NOT POSSIBLE. The information on this card is required in the upgrade process. Also, this card is necessary as the certification for repair (including recovery). When repair is required for the navigation system, the updated data cannot be compensated if you fail to submit this card. For future reference, fill in "DEVICE NUMBER" (Device Number, Device#) of your navigation system.	



Pioneer sound.vision.soul

Destination Information Map

Volume Regional Settings Hardware Default Locations Reorganized Factory Settings

Demo Mode Modify Current Settings Restore Factory Settings

CNDV-700HD PASSWORD TOOL

HOME HELP FRANÇAIS

Device Number:

Media Number:

SEND

Welcome to the CNDV-700HD Password Tool

For detailed instructions on how to use this tool, please see **Step 1** in the **Operation Manual for Updating** included in the CNDV-700HD package. For additional assistance, please click on the **Help** button above.

Easy Instructions


- Input the 16 digit Device Number into the appropriate box above.
- Input the 20 digit Media Number into the appropriate box above.
- Press the **SEND** button.

Device Number & Media Number input boxes and SEND button

Step 9:
Take the completed CNDV-700HD Media Number card and log-on to:
www.pioneernavigationupdate.com

Step 10:
Type the 16 digit Device Number into the appropriate box.
Type the 20 digit Media Number into the appropriate box.

Double check that the numbers are correct and press the "SEND" button.




Password

Step 11:

Your password will be shown on this screen. Please write down or print this page, this password is required to continue installation.

**** NOTE ****

This password is unique and can ONLY be used with this Device Number and Media Number combination.




Step 12:


The remainder of the installation will take approximately 3 hours to complete. The Pioneer navigation system is required to be switched "ON" during the entire software installation.

Because the installation will require the ACC or ignition of the **vehicle** to remain in the "ON" position during the entire installation process, **IT IS STRONGLY RECOMMENDED THAT YOU CONNECT THE VEHICLE TO A CHARGING SYSTEM PRIOR TO CONTINUING THE INSTALLATION.**



Failure to properly connect a charging system can result in damage to the vehicle electrical system and/or battery.



If power is lost during the update, the software installation may fail and damage to the Pioneer navigation system may result.



Open / Close button



Yes touchscreen button

Step 13:

Please park the vehicle safely and apply the parking brake.

Because the installation will require the ACC or ignition of the vehicle to remain in the "ON" position during the entire installation process, **IT IS STRONGLY RECOMMENDED THAT YOU CONNECT THE VEHICLE TO A CHARGING SYSTEM PRIOR TO CONTINUING THE INSTALLATION.**

On the Pioneer navigation system, press the "Open / Close" button and insert the CNDV-700HD disc into the disc loading slot.


Step 14:

After a short delay*, the screen above will appear.


On the Pioneer navigation system, press the "Yes" touchscreen button to continue the installation.

(Press "No" to abort the installation and continue at a later time.)

* Because the CNDV-700HD is a system disc, it may take up to one minute to initialize and display this screen.



Yes touchscreen button



OK touchscreen button

Step 15:

If you have completed steps 1-11 of this walkthrough, you will have a password to continue.

On the Pioneer navigation system, press the “Yes” touchscreen button to continue the installation.

If you have not completed steps 1-11 of this walkthrough, please press the “No” touchscreen button to display the Device Number of the Pioneer navigation system or press the “Cancel” touchscreen button to abort the installation and continue at a later time.

Step 16:


After pressing “Yes” in step 15 of this walkthrough, the screen shown above will appear.

Please type in the password generated in Step 11 of this walkthrough using the touchscreen buttons.

When you have finished typing in the password, please double check to make sure it is correct and press the “OK” touchscreen button to continue.



**You cannot abort the installation after pressing "Yes" in this step.
Please make sure the Pioneer navigation system can be switched "ON" for the remaining software installation.
The remainder of the installation will take approximately 3 hours to complete.**






Yes touchscreen button

Step 17:

After the system authenticates the password, the screen shown above will appear.

The remainder of the installation will take approximately 3 hours to complete. The Pioneer navigation system is required to be switched "ON" during the entire software installation. Because the installation will require the ACC or ignition of the vehicle to remain in the "ON" position during the entire installation process, **IT IS STRONGLY RECOMMENDED THAT YOU CONNECT THE VEHICLE TO A CHARGING SYSTEM PRIOR TO CONTINUING THE INSTALLATION.**

On the Pioneer navigation system, press the "Yes" touchscreen button to reboot and begin the software installation.
(Press "No" to abort the installation and continue at a later time.)



OK touchscreen button

Step 18:

The Pioneer navigation system will restart and then the update will begin.

The progress screen above will be displayed during the update.

Please check the software installation progress periodically during the update.

Step 19:

After approximately 3 hours, the screen above will appear.

The software installation is almost complete.

On the Pioneer navigation system, press the "OK" touchscreen button to initialize the final installation.




During this step

NEVER

turn off the ACC or ignition of the vehicle or cut the power to the Pioneer navigation system.

If power is lost during this step, the software installation may fail and damage to the Pioneer navigation system may result.

Installation failure during this step will REQUIRE the system is serviced by a Pioneer Authorized Service Center.




Step 20:

This is the final software installation screen. This program update may take several minutes.

Once the update is complete, the system will restart.

It is important to NEVER interrupt the Pioneer navigation system or cut the power to the Pioneer navigation system during this step.




Version Number

Step 21: Congratulations!

You have successfully completed the CNDV-700HD software installation.

You can confirm that the installation was successful by checking the Version Number. Please repeat steps 4-8 of this walkthrough to access the Service Information screen and the Version Number information.

The version number should now be 02.0000 or higher.



Frequently Asked Questions & Technical Support

Help

If you experience any problems or technical difficulties with the CNDV-700HD software installation, please see the "Frequently Asked Questions & Technical Support" section of

www.pioneernavigationupdate.com

You can access this document by clicking on the "HELP" button found on each page of the website.